

TECHNICAL BULLETIN

TB # 0117.1

DATE: August 22, 2017

PRODUCT: All Elevators (Residential & LULA)

SUBJECT: Fixed Rollers

Please note that we've improved our fixed sling rollers by switching to a different material that isn't prone to developing flat spots, which can cause vibration when a heavier cab is moved after sitting for a period of time.

Custom rollers with the new material (white in color) are on order, however in the meantime we're using a stock roller that's slightly larger than standard. The larger size has been resolved by using eccentric (adjustable) shafts and installing them so that they're adjusted "out", or away from the rails.

Please make sure to use the white rollers in the fixed positions (top rear and bottom front) and adjust them so the green mark is as far away from the rails as possible, then adjust the other rollers as per "TB0815.3 Adjusting new rollers".

Call CE technical support if you require any assistance with this procedure: Toll-free 1-866-209-3421